



- 1 | Unbox the Desk Top ('C'), Modesty Panel ('B') and Leg Pack ('A').
- 2 | Insert and screw 2x Mini-Fix Pins ('a') into the vertical upright of each Leg Frame ('A').
- 3 | Insert 4x Modesty Panel Cams ('b') into the Modesty Panel ('B') with the arrows pointing outwards.
- 4 | With the Legs and Modesty Panel in an upside down position, locate and engage the Leg Frame Mini-Fix Pins ('a') into the Modesty Panel. Once engaged, rotate the Modesty Panel Cams ('b') clockwise 180 degrees using a phillips head screw driver, locking into position.
- 5 | Place the Desk Top ('C') face down on a suitable surface. Locate and engage the Desk Top Cams ('c') in the underside of the Desk Top onto the pre-installed fixings ('d') in the top of the Modesty Panel. Rotate the screws in the Desk Top Cams 90 degrees to secure the Modesty Panel to the Desk Top.  
*Desks 1600mm and 1400mm wide have 3x pre-installed fixings.  
Desks 1200mm, 1000mm and 800mm wide have 2x pre-installed fixings.*
- 6 | Position the 2x Leg Fixing Screws ('e') through the underside of each Leg Frame ('A') and engage into the pre-drilled holes in the underside of the Desk Top ('C') and tighten clockwise using a phillips head screw driver.
- 7 | Cover the Modesty Panel Cams ('b') with the 4x Cam Covers ('f') and carefully rotate the assembled desk into an upright position.

**The Alpha Rectangular Desk is now fully assembled**  
For any further assistance or clarification, please contact sales on +44 (0) 1405 746001