



FLO PLUS TOP MOUNT CLAMP

DYN/026/A34





1 POSITION CLAMP PLATE ONTO WORK SURFACE



2 CONFIGURE SPACER PAD

FOLD





Ensure inside of bracket is flush against back of work surface

▲ IMPORTANT NOTE


FIT CLAMP SCREWS

5 FULLY TIGHTEN SCREWS


CONFIGURE 180° STOP COMPONENT

A IMPORTANT NOTE

Ensure screws are equally tightened







- Do not use this product for any purpose other than that for which it was designed
- Ensure desk/work surface is suitable to take the weight of the arm/s and monitors
- Supported weight must not exceed the maximum load per arm
- Take care when installing as fingers could become trapped

▲ MAINTENANCE AND INSPECTION

- Ensure all screws and fixings are fully tightened and occasionally re-tighten if necessary.
- Clean with a damp cloth. DO NOT use solvents.

∆ DISCLAIMERS

- The use of power tools, lever bars or excessive force during the installation, or re-configuration of the product will invalidate your guarantee
- Failure to observe the recommendations in the use, and configuration of these products may affect your guarantee
- As part of Colebrook Bosson Saunders ongoing product improvement programme, the design of products may change without prior notice and details may vary from those illustrated.


PATENTS

Colebrook Bosson Saunders hold a number of patents and other intellectual property rights covering our products and processes. You can find patent information on our website at:

www.colebrookbossonsaunders.com/patents

Please consider leaving these instructions with the product if further installation may be required by others

DYN-026-A34-INST-B-MAY-2019



| FOLD | FOLD | Print size - A4 | 297mm x 210mm