


HOW TO ADJUST YOUR RH MEREØ


DESIGNED FOR HUMAN
PERFORMANCE

1



HEIGHT OF THE CHAIR

2




SEAT DEPTH

3




BACKREST ANGLE

4



BACKREST HEIGHT

5



UNLOCK THE DYNAMIC
TILT

6



TILT RESISTANCE

7



HEIGHT OF ARMREST

8



WIDTH OF ARMREST

8



NECKREST

